


ASSEMBLY INSTRUCTIONS

Please read the instructions carefully for correct and safe assembly.

1

- Ⓐ BODY x01
- Ⓑ LEG x02
- Ⓒ SHELF x04



2

- | | | | |
|----|---------------|--|-----|
| 01 | JCBC | | x08 |
| 02 | ALLEN BOLT | | x08 |
| 03 | SPRING WASHER | | x08 |
| 04 | FLAT WASHER | | x08 |
| 05 | ALLEN KEY | | x01 |



Phillips head screwdriver
tool needed (not include)



Thank you for
purchasing this
Zuiver product.

ASSEMBLY INSTRUCTIONS

Please read the instructions carefully for correct and safe assembly.






Thank you for
purchasing this
Zuiver product.

zuiver^o

Name product CABINET FACES
Article number 4100082

ASSEMBLY INSTRUCTIONS

Please read the instructions carefully for correct and safe assembly.





Thank you for
purchasing this
Zuiver product.


ASSEMBLY INSTRUCTIONS

Please read the instructions carefully for correct and safe assembly.

HINGE ADJUSTMENT



The door will not be flush
with the side panel.





Side to Side Adjustment
loosen screw A, adjust gap
with screw B and re-tighten
Screw A.

Thank you for
purchasing this
Zuiver product.

ASSEMBLY INSTRUCTIONS

Please read the instructions carefully for correct and safe assembly.



HINGE ADJUSTMENT



Depth Adjustment

loosen screw A, push hinge arm forwards or backwards, re-tighten screw A and secure Screw B with a 1/4 turn clockwise.

The door will appear too far or too close from the front edge of the side panel.



Height Adjustment

loosen screw C, adjust door height and re-tighten screw C.

The door will not be flush with the vertical panel.

* The doors can be adjusted in all 3 directions to create an even fit between doors on this cabinet. Follow the appropriate directions above to adjust door(s) as necessary.

Thank you for
purchasing this
Zuiver product.

FURNITURE TIPPING RESTRAINT FOR CABINET FACES

Young children may be injured by tipping furniture and the use of a tipping restraint is highly recommended.

When properly installed, this restraint could provide protection against the unexpected tipping of furniture due to small tremors, bumps or climbing. We recommend mounting this restraint to a wall stud.

WARNING: This product is only a deterrent. It is not a substitute for proper adult supervision.

TIPPING KIT CHECK LIST


CODE	COMPONENT	QTY
01	PLASTIC STRAP	2
02	SCREW	4
03	NYLON WALL PLUG	4
04	PLASTIC BRACKET	2

SCREWDRIVER TOOL NEEDED
(NOT INCLUDED)

Installation Instruction:

1. Determine the final position of the furniture piece. Mark location on the wall approximately 2" below the plastic bracket (04) mounted to the back of the furniture.
2. Drill a starter hole into the wall stud. If wall stud is not available, drill a hole into the wall and insert nylon wall plug (03). Gently tap plug until the flange of the plug is flush with the wall.
3. Attach a second plastic bracket (04) by inserting and securing the screw (02) to the wall. Refer to picture B.
4. Align the two plastic brackets (04).
5. Thread the plastic strap (01) through both plastic brackets (04) and tighten until snug.
6. Check to make sure that the plastic brackets (04) are firmly installed the plastic strap (01) is secure.
7. Repeat steps 1-6 at other end of furniture piece.

A



BACK SIDE

B

