





Ekol Tv Stand

assembly guide



Valued Customer,

We design and carefully manufacture our products for our customers. We wish that our customers to have fun while they are doing their new furniture

The product you just purchased was subjected to all sorts of tests and controls before sending out to you.

Hope you enjoy your new furniture!!!

Before starting, please check all components and accessories according to the provided list. If you purchased more than one product, to prevent confusion, be sure that you completed the first product, then start the next one. Please make sure that you select correct numbered part and use specific connector to assemble. We do not recommend any modification or rotation in assembly. Please follow the manual carefully.

Furniture parts are going to several manufacturing procedures. During this process, parts can have little dust or marks. Please clean the parts with damp cloth before assembly to get the best result. Usual cleaning would be suffice.





Although all products are carefully manufactured and packed, sometimes we experience damage during transportation. In such cases, please check the damaged part, note the part number written on the part and do not hesitate to contact us


Do not use your furniture for out of purposes. If you would like to use it out of purpose or would like to do some modification or rotation, please contact us for more details.

Please do not expose your furniture with excessive heat, cold and humidity because product can be affected negatively.


before you start



Get required installation tools prepared.




Do not install the product on rough surfaces.







Get help from someone else!




Part1	1x
Part2	2x
Part3	1x
Part4	3x
Part5	2x
Part6	1x
Part7	2x
Part8	2x
Part9	2x
Part10	2x
TOTAL	18x




C02  düzmenteşe 4x	C04  düzmenteşe 4x	A13  4x50 42x	A06  12 mm 42x
A16  Ø8 4x	A40  çivi 17x	A09  3.5x18 20x	A15  -L- 4x


1




2




3




4









5




6








A= menteşe bağlama vidası / to connect the hinge to the door
B= kapak ayar vidası / to arrange the door



oklar kapağın ayarlama yönünü gösterir.
arrows to show the directions for arrangement of doors.


9



17x

A40

10



4x

A13

10

