


DECOROTIKA



İstanbul TV Stand assembly guide

introduction



Valued Customer,

We design and carefully manufacture our products for our customers. We wish that our customers to have fun while they are doing their new furniture

The product you just purchased was subjected to all sorts of tests and controls before sending out to you.

Hope you enjoy your new furniture!!!



Before starting, please check all components and accessories according to the provided list. If you purchased more than one product, to prevent confusion, be sure that you completed the first product, then start the next one. Please make sure that you select correct numbered part and use specific connector to assemble. We do not recommend any modification or rotation in assembly. Please follow the manual carefully.



Furniture parts are going to several manufacturing procedures. During this process, parts can have little dust or marks. Please clean the parts with damp cloth before assembly to get the best result. Usual cleaning would be suffice.



Although all products are carefully manufactured and packed, sometimes we experience damage during transportation. In such cases, please check the damaged part, note the part number written on the part and do not hesitate to contact us


e-mail: sales@decorotika.com
Phone: (201) 282-1510




Do not use your furniture for out of purposes. If you would like to use it out of purpose or would like to do some modification or rotation, please contact us for more details.

Please do not expose your furniture with excessive heat, cold and humidity because product can be affected negatively.


before you start



Get required installation tools prepared.












Do not install the product on rough surfaces.




Get help from someone else!







ACCESSORY LIST

A02  Minifix k18 26x	A23  Minifix M10 26x	A22  12cm oval ayak 5x	A13  4x50 12x	A16  Ø8 1x
A06  18 mm BYZ c 1 32x	A09  3.5x18 30x	A40  çivi 10x	A20  5x70 1x	
C02  düzmenteşe 2x	C04  2x	B01  -L- 1x	A04  Ø8 24x	



GENERAL VIEW





1







2






3






4







A= menteşe bağlama vidası / to connect the hinge to the door
B= kapak ayar vidası / to arrange the door











oklar kapağın ayarlama yönünü gösterir.
arrows to show the directions for arrangement of doors.

5





6











8





9





final look



Enjoy your Decorotika product!



contact@decorotika.com



www.decorotika.us
www.decorotika.com